

**DEVELOPMENT OF TEACHING AIDS FOR DIESEL
INJECTION SYSTEMS**

By

ANDREAS NIKIFOROU

Project Report
Submitted to

the Department of Mechanical Engineering
of the HIGHER TECHNICAL INSTITUTE
Nicosia Cyprus
in partial fulfillment of the requirements
for the diploma of
TECHNICIAN ENGINEER


in

MECHANICAL ENGINEERING

Project Number : M/804

Project Supervisor : Mr. Paraskevas Demetriou
Lecturer in Mechanical Engineering

JUNE 1997



To my family for its support and love

CONTENTS

ACKNOWLEDGMENTS

SUMMARY

CHAPTER 1 - INTRODUCTION - THE FUEL SYSTEM

INTRODUCTION.....	1
1.1 FUEL FILTERS.....	1
1.1.1 Down-Flow.....	2
1.1.1 Operation.....	2
1.1.2 Up-Flow.....	2
1.1.3 Cross-Flow.....	2
1.2 FUEL LIFT PUMP.....	2
1.2.1 Operation.....	3
1.3 THE INJECTION PUMP.....	5

CHAPTER 2 - IN LINE FUEL INJECTION PUMP

2.1 THE IN-LINE PUMP.....	6
2.1.1 Description.....	6
2.1.2 Operation.....	7
2.1.3 Plunger Control.....	8
2.1.4 Delivery Valve.....	9
2.2 FLANGE MOUNTED PUMPS.....	11
2.3 GOVERNORS.....	12
2.3.1(a) Mechanical Governor.....	13
2.3.1(b) Leaf Spring Flyweight Governor.....	15
2.3.1.1 Operation.....	16
2.3.2 Pneumatic Governor.....	17
2.3.2.1 Operation.....	17
2.3.3 Hydraulic Governor.....	18
2.4 EXCESS FUEL AND ENGINE STOP CONTROL.....	18
2.5 BOOST CONTROL UNIT.....	19
2.5.1 Operation.....	20

CHAPTER 3 - BOSCH DISTRIBUTOR-TYPE FUEL-INJECTION PUMPS

INTRODUCTION.....	20
3.1 SUMMARY.....	22
3.1.1 Range of Application.....	22
3.1.2 General Information.....	24
3.2 CONSTRUCTION.....	25
3.3 OPERATION.....	26
3.3.1 Low-Pressure Delivery.....	26
3.3.2 High-Pressure Delivery.....	26
3.3.3 Stroke and Delivery Phases.....	28
3.3.4 Delivery-valve Assembly.....	29
3.3.4.1 Function.....	29
3.3.4.2 Operation.....	29
3.3.5 Return-Flow Restriction.....	30
3.3.5.1 Function.....	30
3.3.5.2 Operation.....	30
3.4 TIMING DEVICE.....	31
3.4.1 Function.....	31
3.4.2 Operation.....	31
3.5 SPEED GOVERNING.....	33
3.5.1 Function of Governors.....	33
3.5.2 Speed Droop.....	33
3.6 VARIABLE-SPEED GOVERNOR.....	35
3.6.1 Function.....	35
3.6.2 Operation.....	35
3.6.3 Starting Position.....	36
3.6.4 Idle Position.....	37
3.6.5 Speed Governing.....	38
3.7 VARIABLE-SPEED GOVERNOR WITH INTERMEDIATE SPRING IN THE DRIVEAWAY RANGE.....	40
3.8 MINIMUM-MAXIMUM SPEED GOVERNOR.....	41
3.8.1 Function.....	41
3.8.2 Operation.....	41
3.9 MINIMUM-MAXIMUM SPEED GOVERNOR WITH PART-LOAD TORQUE CONTROL FOR PASSENGER CARS.....	43
3.9.1 Function.....	43
3.9.2 Operation.....	43

3.10	FULL-LOAD TORQUE CONTROL.....	45
3.10.1	Function.....	45
3.10.2	Positive Torque Control.....	45
3.10.3	Negative Torque Control.....	45
3.10.4	Torque Control with the Delivery Valve Assembly.....	47
3.10.5	Torque Control with the Fulcrum Lever Assembly.....	48
3.10.5.1	Positive torque control with the Fulcrum lever assembly.....	48
3.10.5.2	Negative torque control with the Fulcrum lever assembly.....	49
3.11	ADD-ON MODULES.....	50
3.11.1	Manifold-Pressure Compensator (LDA).....	50
3.11.1.1	Function.....	50
3.11.1.2	Operation.....	50
3.11.2	Altitude-Pressure Compensator (ADA).....	52
3.11.2.1	Function.....	52
3.11.2.2	Operation.....	52
3.11.3	Load-Dependent Star of Pump Delivery (LBF).....	53
3.11.3.1	Function.....	53
3.11.3.2	Operation.....	53
3.11.4	Cold-Start Accelerator (KSB).....	55
3.11.4.1	Function.....	55
3.11.4.2	Remote-Controlled KSB.....	55
3.11.4.3	Automatic KSB.....	56
3.11.4.4	Additional Function of Automatic KSB.....	57
3.12	SHUTOFF.....	59
3.12.1	Mechanical Shutoff Device.....	59
3.12.2	Electric Shutoff Device (ELAB).....	60
3.12.2.1	With Pulling Electromagnet.....	60
3.12.2.2	With Pushing Electromagnet.....	60
3.13	INSTALLATION POSITION OF PUMP.....	61
3.13.1	Lever Positions.....	61
3.14	INSTALLATION AND DRIVE.....	62
3.14.1	Supporting the Pump.....	62
3.15	LAYOUT OF LINES.....	64
3.15.1	Gravity Feed.....	64
3.15.2	Suction Feed.....	65
3.15.2.1	With Pre-supply Pump.....	65
3.15.2.2	Without Pre-supply Pump.....	66

CHAPTER 4 - CAV FUEL INJECTION PUMP

4.1	INTRODUCTION.....	68
4.1.1	General.....	68
4.1.2	Working Principle.....	70
4.2	DESCRIPTION AND METHOD OF OPERATION.....	73
4.2.1	Typical Fuel System.....	73
4.2.2	Metering of Fuel.....	75
4.2.3	Pumping and Distribution of Fuel.....	76
4.2.4	Transfer Pump and Regulating Valve.....	76
4.2.5	Two Speed Governor.....	79
4.2.6	Anti-stall Device.....	79
4.2.7	Scroll Plates.....	80
4.2.8	Scroll Plate Principle.....	83
4.2.8.1	In Excess Fuel Position.....	83
4.2.8.2	In Maximum Fuel Position.....	83
4.2.9	Latch Valve and Rotor Vent Switch Valve.....	85
4.2.10	Automatic Advance and Start Retard Unit.....	87
4.2.11	Manual Idling Advance Lever.....	88
4.2.12	Head Locating Fitting - Damper Assembly.....	89
4.2.13	Hydraulic Head and Rotor.....	90
4.2.14	High Pressure Delivery Valves.....	91
4.2.15	Pump Drive Shaft.....	91
4.2.16	Pressuring Valve.....	92
4.2.17	Solenoid Shut-off Valve.....	93
4.3	OVERHAUL.....	94
4.3.1	Service Problems.....	94
4.3.2	Maintenance Records.....	94
4.3.3	Governor.....	94
4.3.4	Typeplate.....	95
4.3.5	Overhaul Procedure.....	95
4.4	DISMANTLING.....	98
4.4.1	Timing Cover Plate.....	98
4.4.2	Excess Fuel Linkage Spring.....	98
4.4.3	Throttle Control Bracket and Solenoid.....	99
4.4.4	Pressurizing Valve.....	100
4.4.5	Throttle Lever Assembly.....	101
4.4.6	Vent Screw.....	101
4.4.7	Governor Control Cover.....	102
4.4.8	Main Governor Spring and Throttle Shaft.....	102
4.4.9	Governor Arm and Control Bracket Assembly.....	104
4.4.10	End Plate and Regulating Valve Assembly.....	105
4.4.11	Delivery Valve Assemblies.....	106
4.4.12	Transfer Pump.....	107
4.4.13	Automatic Advance and Start Retard Unit.....	108
4.4.14	Latch Valve.....	110
4.4.15	Rotor Vent Switch Valve.....	111

4.4.16	Hydraulic Head.....	111
4.4.17	Pump Housing and Drive Shaft Assembly.....	112
4.5	COMPONENT INSPECTION AND RENEWAL.....	115
4.6	RE-ASSEMBLY.....	118
4.6.1	Drive Shaft.....	118
4.6.2	Governor Weight Assembly.....	120
4.6.3	Pump Housing and Drive Shaft Assembly.....	121
4.6.4	To check the Drive Shaft End Float.....	122
4.6.5	Rear Bearing Cam and Scroll Plates.....	124
4.6.6	Hydraulic Head.....	126
4.6.7	Automatic Advance Housing Assembly and Damper.....	129
4.6.8	Latch Valve and Rotor Vent Switch Valve.....	131
4.6.8.1	Latch Valve.....	131
4.6.8.2	Rotor Vent Switch Valve.....	132
4.6.9	Automatic Advance and Start Retard Unit.....	133
4.6.10	Transfer Pump.....	135
4.6.11	End Plate and Regulating Valve Assembly.....	137
4.6.12	Governor Arm Control Bracket Assembly.....	139
4.6.13	To set the Governor Linkage.....	141
4.6.14	Control Bracket Assembly.....	141
4.6.15	Governor Control Cover.....	142
4.6.15.1	Idling Shaft and Lever.....	142
4.6.15.2	Excess Fuel Shaft.....	142
4.6.16	Throttle Shaft and Anti-stall Components.....	144
4.6.17	Maximum Fuel Adjustment Screw.....	145
4.6.18	Vent Screw.....	146
4.6.19	Throttle Lever Assembly.....	146
4.6.20	Pressuring Valve.....	147
4.6.21	Delivery Valve Assemblies.....	149
4.6.22	Solenoid Assembly.....	149
4.6.23	Timing Cover Plate.....	150
4.6.24	Throttle Control Bracket- when fitted.....	150
4.6.25	Excess Fuel Linkage Spring.....	152
4.7	PRE-TEST PROCEDURE.....	153
4.7.1	Pressure Testing.....	154
4.7.2	Seal Testing.....	154
4.7.3	Test Procedure.....	155
4.7.4	Test Machine.....	155
4.7.5	Drives for Up-Rated Pumps.....	155
4.7.6	Supported Shaft.....	155
4.7.7	Unsupported Shaft.....	156
4.7.8	General Procedure.....	157
4.7.9	Priming.....	157

4.8	TO TEST.....	158
4.8.1	Pump Output.....	158
4.8.2	Shut-off Solenoid.....	158
4.8.3	Maximum Fuel Setting.....	158
4.8.4	Governor Testing.....	159
4.8.5	Governor Setting.....	159
4.8.6	Transfer Pump Setting.....	159
4.8.7	Pressurized Cam Boxed.....	160
4.8.8	Advance Unit Setting.....	162
4.8.9	Manual Idling Advance Device.....	164
4.8.10	Timing.....	165
4.8.11	Sealing Pumps.....	169

CHAPTER 5 - FUEL INJECTORS AND SERVICING -TESTING FUEL INJECTORS

5.1	FUEL INJECTORS.....	170
5.1.1	Construction.....	170
5.1.2	Operation.....	171
5.2	NOZZLE TYPES.....	172
5.3	LOWARD HIGH SPRING NOZZLE HOLDERS.....	174
5.4	CAV MICROJECTOR.....	175
5.4.1	Operation.....	175
5.5	SERVICING AND TESTING FUEL INJECTORS.....	176
5.5.1	Nozzle Testing.....	177
5.5.2	Dismantling the Injector.....	179
5.5.3	Reassembly.....	183
5.5.4	Servicing Faulty Injectors.....	184

CHAPTER 6 - TROUBLE SHOOTING

6.1	ENGINE OPERATION TROUBLES AND THEIR REMEDIES.....	189
6.2	FUEL INJECTION PUMP FAULTS.....	194
6.3	DISTRIBUTOR - TYPE INJECTION PUMP TROUBLES.....	195

CHAPTER 7 - PRESENTATION OF CALIBRATION MACHINE

7.1	CALIBRATION MACHINE FOR PUMPS AND INJECTORS.....	196
7.1.1	Introduction.....	196
7.1.2	Function.....	197
7.1.3	The Main Parts of the Construction.....	198
7.1.3.1	The Injection Pump.....	198
7.1.3.2	The injectors.....	198
7.1.3.3	The Little/Small Pump.....	199
7.1.3.4	The Filter.....	200
7.1.3.5	The Pipes.....	200
7.1.3.6	The Tups.....	200
7.1.3.7	The Motor.....	200
7.1.3.8	The Pressure Gauge.....	200
7.2	MANUAL.....	201

CHAPTER 8 - CONCLUSION

8.1	CONCLUSION.....	202
-----	-----------------	-----

APPENDICES

APPENDIX A

- A1. List of Torque Values
- A2. Special Tools

APPENDIX B

Diagrams and Drawings of the Fuel Pumps

APPENDIX C

Standards of Calibration Machine

ACKNOWLEDGMENTS

I wish to express my deep gratitude to a number of people for their valuable help for the completeness of this project.

I am greatly indebted to my project supervisor, Mr. Paraskevas Demetriou, who was always on my side, encouraging me and helping me for this work.

Acknowledgment is also made to the plant laboratory assistant of HTI Mr. Charalambos Kalogirou for his assistance during the practical part of my project work.

I would also like to thank my father for helping me to put together the information I collect, and to construct the Calibration Machine.

It would be a great omission not to express my sincere gratitude to my professors at the HTI for the previous knowledge that they have offered me during my studies at the Higher Technical Institute.

Finally, I would like to express my love and thanks to my family for their encouragement and moral support.

SUMMARY

This project is divided into seven (7) Chapters :

Chapter 1 : Introduction - The Fuel System

Chapter 2 : In Line Fuel Injection Pump

Chapter 3 : Bosch Distributor - Type Fuel Injection Pumps

Chapter 4 : CAV Fuel Injection Pump

Chapter 5 : Fuel Injectors and Servicing - Testing Fuel Injectors

Chapter 6 : Trouble Shooting

Chapter 7 : Presentation of Calibration Machine

The first chapter, which is the Introduction of the project, describes the operation and the function of the Fuel Injection System as well as the several filters that are used.

In the next three chapters a detailed reference is made for the three kinds of Fuel Injection Pumps. The In-Line Fuel Injection, the Bosch Distribution and the CAV Fuel Injection Pump. Their functions and their operations are described in details.

In the fourth chapter - CAV Fuel Injection Pump - which is related also with the pump which was used in the Calibration Machine construction, a more detailed analysis is performed for the Pre-Test Procedure and for the Testing of the pump.

In the fifth chapter, a general reference is made for the Injectors, their Service and the Testing Procedure.

In the sixth chapter troubles which may possibly have their root in the injection system or its associated parts, are presented.

In the seventh, the Calibration Machine is presented. Its function and operation is described as well as its purpose of use. The instructions of use are also presented (Manual).